

'00' Kits of Etched Brass with Metal details



LLETY DERWEN
 LLECHRYD
 CARDIGAN
 SA43 2NL

G.W.R. 6T MEAT VAN

DIA. XI.

GENERAL:

Remove parts from fret with sharp craft knife, file off remainder of retaining pip with needle file.

ASSEMBLY:

- (1) With the aid of steel or similar rectangular block bend sides of main body (1) etched detail to the outside, solder sides and ends together.
- (2) Take end vents 6 and bend side supports on line x (see fig. 1) to 90°. The end vents have been purposely made larger for ease of handling and less risk of distortion on the bend lines. Next with a Swiss file or similar, file as per dotted line A-B as fig. I when satisfied solder to both ends of body. Next with a razor saw or similar cut sides of vent at point Y (see fig. I) two planks up, bend up and down until parted. Clean up with fine emery paper.
- (3) Carefully bend the flange top of 'W' iron plates (2) to 90° away from etched brake detail. Attach to underside of wagon body ensuring that the axle holes are opposite and the wagon sits level on its wheels.
- (4) Carefully bend U/F channels (3) rivet detail within the channel. This is best done by bending one lip in a vice then putting a piece of 1/8th brass against the inside right angle, trapping in a vice with unbent lip sticking proud, with a straight edge bend down other lip. Affix both channels to underside of body, edges level with outside of body.
- (5) Attach buffer beams (4 and 5) and buffers.
- (6) Attach hand-brake lever and support 8, 10. Attach axle boxes and vac. cylinders, simulate brake gear detail with wire provided. **OPEN UP HOLES IN BRAKESHOOES ETC. TO SUIT 0.45 HANDRAIL WIRE.**
- (7) Attach door hinges 7, door catch 9, and lamp-irons.
- (8) Attach roof with aid of elastic bands and trim back to approx. 1/4" overhang.

PAINTING:

G.W.R. Wagon Brown with Yellow Lettering.

